

Pro Stitch Assembly Instructions

For most planting conditions the lightest downpressure setting is needed for optimum closing results. Start out in the lightest setting and add pressure only when needed.

Pro-Stitch Closing wheels are recommended to be staggered (one in the front hole and one in the rear hole) and 1.75" on the bottom of the closing wheels. For the perfect stitch results!

Pro Stitch Closing wheels run out of time due to soil pressure creating the perfect stitch results.

7/8" Spacers available so no washers are needed to get the right spacing on most planters!

A carriage bolt can be added halfway up the slot on the tailpiece, for lighter soil conditions looser soil, and/or conventional tillage.



Thanks for choosing Pro-Stitch Closing wheels. If you have any questions call your local rep, or the main office at (605)487-7766